

OXFORD TABLES ASSEMBLY INSTRUCTIONS

PARTS INCLUDED:

1. ONE (1) ALUMINUM TABLE TOP WITH APRON
2. FOUR (4) ALUMINUM TABLE LEGS

ITEMS INCLUDED IN THE HARDWARE KIT:

- A. TWELVE (12) HEADLESS BOLTS
- B. TWELVE (12) FLAT WASHERS
- C. TWELVE (12) LOCK WASHERS
- D. TWELVE (12) HEX-NUTS

STEP 1:

PLACE THE TABLE TOP ON A PADDED SURFACE WITH BOTTOM OF TOP FACING UPWARD.

STEP 2:

PLACE ONE LEG IN A CORNER OF THE TABLE APRON AND LINE-UP THE TWO HOLES IN THE LEG WITH THE HOLES IN THE CORNER SECTION OF THE APRON.

STEP 3:

PLACE TWO HEADLESS BOLTS (A) INTO EACH OF THE HOLES. USE A FLAT-HEAD SCREW DRIVER TO HAND TIGHTEN (FIGURE 1)

STEP 4:

PLACE ONE FLAT WASHER (B), THEN ONE LOCK WASHER (C), AND ONE HEX-NUT (D) ONTO EACH OF THE BOLTS. TIGHTEN USING A HEX-WRENCH. HAND TIGHTEN ONLY, DO NOT USE ELECTRIC DRILL. (FIGURE 1)

STEP 5:

REPEAT STEPS 2 THROUGH 4 FOR THE OTHER THREE TABLE LEGS.

STEP 6:

USING TWO PEOPLE FOR LARGER TABLES, CAREFULLY LIFT THE ASSEMBLED TABLE AND PLACE IT UPRIGHT.



FIGURE 1

