

SUMMER CLASSICS

PROVANCE CHAISE LOUNGE

PARTS INCLUDED:

- A. ONE (1) SEAT
- B. TWO (2) FRONT LEGS
- C. TWO (2) SIDE ARMS
- D. ONE (1) BACK
- E. TWO (2) WHEEL HUBS
- F. ONE (1) AXLE
- G. ONE (1) ADJUSTMENT BAR

TOOLS REQUIRED:

- 1. ONE (1) FLAT-HEAD SCREWDRIVER
- 2. ONE (1) PHILLIPS SCREWDRIVER
- 3. ONE (1) ADJUSTABLE OR SOCKET WRENCH
- 4. TWO PEOPLE ARE RECOMMENDED FOR ASSEMBLY

ITEMS INCLUDED IN THE HARDWARE KIT:

- H. SIX (6) LONG BOLTS
- I. TWO (2) SHORT BOLTS
- J. FOUR (4) HEADLESS BOLTS
- K. EIGHT (8) METAL WASHERS
- L. FOUR (4) LARGE NYLON WASHERS
- M. FOUR (4) SMALL NYLON WASHERS
- N. EIGHT (8) NUTS
- O. TWO (2) END CAPS
- P. EIGHT (8) LOCK WASHERS
- Q. TWO (2) PLASTIC AXLE SLEEVES



STEP 1:

Place the four headless bolts (J) in the four threaded holes in the front corners of the seat (A), with the slotted ends facing outward. Tighten with a flat-head screwdriver. Position the front legs (B) on the front of the seat, inserting the headless bolts through the leg holes. Place one metal washer (K), one lock washer (P), and then one nut (N) on each headless bolt (H). Hand-tighten only.

STEP 2

With another person, raise the seat and insert four long bolts through the holes in the side arms (C) and through the holes in the seat. Place one metal washer, one lock washer, and then one nut on each long bolt. Hand-tighten only.

STEP 3

One person should position the back (D) between the side arms, lining up the holes in the back of the side arms with the holes at the bottom of the back. The other person should insert a small nylon washer (M) between the holes and screw two long bolts through the holes from the outside. Hand-tighten only.

STEP 4

First, place the plastic axle sleeves (Q) onto the axle. Then insert the axle (F) through the holes in the back legs of the seat. Then insert each end of the axle through a large nylon washer (L), a wheel hub (E), and secure with a second nylon washer and an end cap (O). Make sure the wheel hub is positioned with the longer end facing inward.

STEP 5

Insert the two short bolts (I) through the back, through a small nylon washer (M) and then into the adjustment bar (G).

STEP 6

Tighten all bolts.

