-SUMMER 🗩 CLASSICS -

# CAST WICKER / PROVANCE ROUND END TABLE **ASSEMBLY INSTRUCTIONS**

## ITEMS INCLUDED IN THE HARDWARE KIT:

- A EIGHT (8) STAINLESS STEEL NUTS
- B EIGHT (8) STAINLESS STEEL WASHERS
- C EIGHT (8) STAINLESS STEEL LOCK WASHERS
- D EIGHT (8) STAINLESS STEEL ALL-THREAD
- HEADLESS BOLTS WITH SLOTTED END

# PARTS INCLUDED:

E - FOUR (4) CAST ALUMINUM LEGS WITH LEVELING FEET F - ONE (1) ALUMINUM CYLINDER

#### **TOOLS REQUIRED:**

- FLAT-HEAD SCREWDRIVER
- SOCKET WRENCH OR ADJUSTABLE WRENCH

### STEP 1:

PLACE THE EIGHT HEADLESS BOLTS (D) INTO THE FOUR LEGS WITH THE SLOTTED END FACING OUTWARD, AS ILLUSTRATED IN FIGURE 1. TIGHTEN USING A FLAT HEAD SCREWDRIVER.

#### STEP 2:

INTERLOCK ALUMINUM CYLINDER (F) WITH TABLE LEG BY INSERTING HEADLESS BOLTS (D) THROUGH PRE DRILLED HOLES IN CYLINDER.

### **STEP 3:**

ATTACH ONE WASHER (B) AND ONE LOCK WASHER (C) AS SHOWN AND THEN SCREW ONE NUT (A) ON TO EACH BOLT, AS SHOWN IN FIGURE 2. HAND TIGHTEN ONLY.

#### STEP 4:

REPEAT STEP 3 UNTIL ALL LEGS ARE ATTACHED.

#### **STEP 5:**

STAND UPRIGHT. FOLLOW TABLE TOP INSTRUCTIONS TO ATTACH TABLE TOP. ONLY HAND TIGHTEN TABLE TOP TO BASE. AFTER TOP IS ATTACHED, TIGHTEN NUTS (A) SECURING ALUMINUM CYLINDER TO LEGS, THEN TIGHTEN NUTS SECURING TOP TO BASE. DO NOT OVERTIGHTEN. DO NOT USE ELECTRIC DRILL.

