SOMERSET CHAISE LOUNGE

PARTS INCLUDED:

A. ONE (1) SEAT B. ONE (1) BACK

TOOLS REQUIRED:

1. ONE (1) PHILLIPS SCREWDRIVER

ITEMS INCLUDED IN THE HARDWARE KIT:

C. TWO (2) LONG BOLTS

STEP 1:

Place the four headless bolts

STEP 2

With another person, raise the seat and insert four long bolts through the holes in the side arms



STEP 3

One person should position the back (D) between the side arms, lining up the holes in the back of the side arms with the

STEP 4

First, place the plastic axle sleeves (Q) onto the axle. Then insert the axle (F) through the holes in the back legs of the seat.

