



ASSEMBLY INSTRUCTIONS

Jean Chandelier- White
SCH-169000

- (1) Prior to assembly, unwrap all parts and components on a carpeted or non-abrasive surface to protect the finish.
- (2) Thread wire through chain every 3 links as shown and hang the chandelier.
- (3) Connect the wood frame and top junction box with 6 suspension rods, one of the rods with cord inside, please pull it straight before hang onto the product.
- (4) Screw metal frame underneath the wood body with 6 screws.
- (5) Attach the drop onto chandelier as shown.

