

Step 1: Find a location on wall for the center of the mirror and mark it.

Step 2: Drill pilot hole for wall anchor at marked point.

Step 3: Insert or drill wall anchor into pilot hole.

Step 3: Carefully hang mirror on the wall anchor with the metal wire.

We hope you enjoy your Gabby product!