(1) Attach beads as shown.
(2) Thread wire through chain every 3 links.

white negative Pole   black positive Pole
green ground wire

earthing conductor

A

A

B

A   B