



ASSEMBLY INSTRUCTIONS

Sharon Pendant
SCH-151210

- (1) Put the metal frame into the glass cylinder(B) and keep the metal hole(F) aligned with the glass hole(G)
- (2) Attach the Rubber Seal(D) and Nut(C) to the metal hole(F) by screwing threaded rod(E) through glass hole(G).
- (3) Thread wire through chain every 3 links

