



ASSEMBLY INSTRUCTIONS

Whitney Chandelier

SCH - 153200

- (1) Screw (G) centre pole to (F) chandelier base.
- (2) Screw (H) metal part to (G) centre pole.
- (3) Attach beads as shown.
- (4) Tighten the screw (I) using the Allen wrench (J) provided.

- (5) Thread wire through chain every 3 links.

white negative Pole
black positive Pole
green ground wire
earthing conductor

