CLARO COLLECTION OUTDOOR ACRYLIC COUNTER AND BARSTOOLS 41092 - 41082 - 410946 - 410846

WE RECCOMEND 2 ADULTS FOR HARDWARE INCLUDED:

A -Clear Acrylic Seat Panel F - 1/4" Flat Washer B - Base G - 1/4" Lock Nut

TOOLS INCLUDED: C -Plastic Spacer

-4mm Hex Wrench D -1/4" x 1" Hex Head Bolt

-10mm Crescent Wrench E - 1/4" Lock Washer

Prior to assembly, unwrap all parts and components on a carpeted or non-abrasive surface.

Step 1: Unwrap both the base and seat from the packaging.

Place the seat on top of the base with 4 Plastic Spacers(C) aligned to the 4 holes in the top of the base.

Step 2: Insert Hex Head bolt(D) through the 4 holes in the seat. Next, thread the Washer(F), Lock Washer(E) and Lock Nut(G) under the seat and hand-tighten.

Step 3: Use the Hex wrench & 10mm Crescent Wrench provided to tighten bolts by hand. Once tightened, your stool is ready to use. Enjoy!







